


Exhaust Fan Wiring Diagram

This diagram shows the connection between our ESRAD-102 Remote CO2 Storage Safety Alarm and an exhaust fan requiring 120VAC 1 0A to operate.

The same diagram can be used to connect any of our CO2 meters, transmitters or wall monitors that include an on-board 120VAC, 3A normally open (NO) relay.



Example Relay Purchased Online:
Model 2W928 10A, 120VAC DPDT Relay
Model 10E075 Square Relay Socket